




## Synergy Brushless ESC Program Card


The FlightTech Synergy Program Card is an easy to use plug-and-play programming system that allows the user to change the parameters of any Synergy Brushless controller quickly and easily without having to use conventional throttle-stick programming.

Simply set the parameter switches, plug your Synergy controller into the Program Card, and press the 'TRANSFER' button to update the ESC.

### Program Card



1. First set the required ESC settings by using the switches on the Program Card.
2. Connect up the power system components as shown below and plug the ESC's JR connector into the Program Card.



3. Connect your battery to the ESC, you will hear 3 tones to indicate a correct connection between the ESC and the Program Card. (note the OPTO controllers require an extra power source such as an RX pack)
4. Press the 'TRANSFER' button, you will hear a further 3 beeps to indicate the settings have been sent to the controller.
5. If the LED flashes during the programming it indicates there is an error with your settings, check the settings and try again.
6. When finished disconnect the ESC from the Program Card.